

MONITOR 441 SERVICE PARTS LIST

MONITOR 441 SERVICE PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	6400	SPILL TRAY	55	6204	PHOTO COUPLER IC12
2	5019	LEG	56	6251	POWER TRANSFORMER
3	6301	AIR SUPPLY HOSE (A)	57	6326	AIR LINE
4	6302	AIR SUPPLY HOSE (B)	58	6343	AIR PRESSURE SWITCH
5	6303	CONSTANT LEVEL VALVE	59	6136	RUBBER BUSH
6	6304	C.L.V. STRAINER	60	6463	OVER HEAT THERMOSTAT
7	6344	STRAINER GASKET	61	6464	FAN THERMOSTAT
8	6467	FUEL PIPE	62	6137	CORD CONNECTOR
9	6450	SOLENOID PUMP	63	6466	JUNCTION BOX COVER
10	6357	GASKET (1)	64	6139	POWER SUPPLY CORD
11	6401	BURNER	65	4833	CORD BUSHING
12	6363	BURNER CLOTH	66	6037	LEVEL GUIDE
13	6358	ROPE GASKET	67	6138	CARRYING HANDLE
14	6311	HEATER	68	6186	SENSOR ASSY
15	6115	GASKET (3)	69	6278	SLIDE SWITCH ASSY
16	6402	IGNITER BRACKET	70	6206	SLIDE SWITCH COVER
17	6354	HEATER COVER PACKING	71	6207	SLIDE SWITCH PANEL
18	6403	IGNITER COVER	72	6208	SLIDE SWITCH KNOB
19	6355	FLAME DETECTIVE PLUG	73	4004	JOINT PIPE
20	6119	PLUG PACKING	74	6407	AIR DAMPER (E)
21	6196	FL PLUG BRACKET	75	6408	AIR DAMPER (S)
22	6313	GASKET (4)	76	6145	AIR SUPPLY HOSE ASSY
23	6314	HEAT EXCHANGER ASSY	77	4014	EXHAUST OUTLET CAP
24	6122	GASKET (6)	78	4016	AIR PORT O RING
25	6123	EXHAUST DUCT	79	4006	PIPE HOLDER
26	6176	O-RING (P39)	80	4008	HOSE BAND
27	6315	OIL SUMP PIPE	81	4805	AIR OUTLET CAP
28	6164	JOINT SEAL PACKING	82	6147	FLUE PIPE ASSY
29	6352	FUEL NOZZLE	83	6148	SLEEVE FLANGE SET
30	6353	FUEL NOZZLE COVER	84	6075	FAN
31	6404	BASE TRAY RETAINER	85	6453	CIRCULATION MOTOR
32	6124	WINDOW GASKET	86	6454	BLOWER GUARD
33	6125	WINDOW FRAME GASKET	87	6455	WIRING GUARD
34	6405	WINDOW GLASS	88	6332	UNDER COVER
35	6350	WINDOW BASE GASKET	89	6409	LOUVER
36	6317	CHAMBER GASKET	90	6456	CONTROL COVER
37	6349	COMBUSTION CHAMBER	91	6457	FRONT COVER
38	6356	COMBUSTION RING ASSY	92	6458	LAMP PANEL
39	6321	CHAMBER CAP	93	6266	SWITCH & LAMP ASSY
40	6322	CONDENSER (2.5 μ FD)	94	6337	TOP COVER
41	6323	BLOWER ASSY	95	6338	RESISTOR
42	6406	DAMPER SOLENOID ASSY	96	6465	CABINET ASSY
43	6324	SUCTION CASE A ASSY	97	6194	WALL CLAMPS
44	6144	SEAL PACKING	98	6197	SCREW SET FOR FLUE PIPE
45	6348	MOTER FOR COMBUSTION	99	6459	CARTON BOX
46	6451	PWB ASSY	100	6342	CUSHION SET
47	6461	PWB SPACER CLIP (A)	101	1153	OWNERS GUIDE
48	6462	PWB SPACER CLIP (B)	102	8216	TOUCH-UP PAINT (WHITE)
49	6253	MICROPROCESSOR	103	8217	GLUE
50	6203	BUZZER	104	8219	TOUCH-UP PAINT (GREY)
51	6172	FUSE (250V 10A)			
52	6173	FUSE (250V 2A)			
53	6452	CAPACITOR (1.5 μ FD)			
54	6187	TR ARRAY (M54563P) IC4			

The highlighted parts are for an older 441 (pre-1998). Review listing & photos carefully or contact us prior to ordering.

The part #s for the newer 441's are highlighted in green.

Please see listing for details part # 6450. ONLY fits newer 441's - Will need a conversion kit (part # 6468) if you have the older 441

