



- 75 Carton Box
- 76 Cushion Set
- 77 Owners Guide

MONITOR 21 EXPLODED VIEW

MONITOR 21 SERVICE PARTS LIST

MONITOR 21 SERVICE PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	6100	SPILL TRAY	50	6149	UNDER COVER
2	6101	AIR SUPPLY HOSE A	51	6150	LOUVER
3	6102	AIR SUPPLY HOSE B	52	6151	OVER HEAT PROTECTOR
4	6103	FUEL PIPE0	53	6152	FAN THERMOSTAT
5	6104	FUSIBLE VALVE	54	6153	FRONT COVER
6	6105	CONSTANT LEVEL VALVE	55	6154	SWITCH ASSY
7	6106	CONSTANT LEVEL VALVE STRAINER	56	6155	LAMP ASSY
8	6107	AIR LINE	57	6156	TOP COVER
9	6108	SOLENOID PUMP PACKING	58	6157	LAMP PANEL
10	6109	SOLENOID PUMP	59	6158	FUEL TANK COVER
11	6110	OIL SUMP PIPE	60	6159	FUEL TANK ASSY
12	6111	FUEL SUMP	61	6160	BLOWER GUARD
13	6112	GASKET (1)	62	6161	CIRCULATION MOTOR
14	6113	BURNER CLOTH	63	6162	RESISTOR
15	6114	GASKET (2)	64	6163	AIR PACKING SET
16	6115	GASKET (3)	65	6164	JOINT SEAL PACKING
17	6116	HEATER	66	6165	FLOAT SWITCH
18	6117	HEATER COVER PACKING	67	6166	CABINET ASSY
19	6118	FLAME DETECTIVE PLUG	68	6167	MICROPROCESSOR (M50940)
20	6119	PLUG PACKING	69	6168	RELAY (A)
21	6120	GASKET (4)	70	6169	RELAY (B)
22	6121	HEAT EXCHANGER ASSY	71	6170	CAPACITOR (1.5MFD)
23	6122	GASKET (6)	72	6171	BUZZER
24	6123	EXHAUST DUCT	73	6172	FUSE (250V 10A)
25	6124	WINDOW GASKET	74	6173	FUSE (250V 10V)
26	6125	WINDOW FRAME GASKET	75	6174	CARTON BOX
27	6126	WINDOW BASE GASKET	76	6175	CUSHION SET
28	6127	COMBUSTION CHAMBER ASSY	77	1142	OWNERS GUIDE
29	6128	BURNER CAP	78	6176	O-RING (P39)
30	6129	BAFFLE ASSY	79	6177	OIL FILTER
31	6130	CHAMBER GASKET	80	6178	FLOAT SWITCH PACKING
32	6131	CHAMBER CAP	81	6179	FUEL TANK CAP
33	6132	POWER TRANSFORMER	82	6180	FAN BLADE
34	6133	PWB ASSY	83	6181	COMBUSTION RING ASSY
35	6134	PWB SPACER CLIP (A)	84	6182	BURNER
36	6135	PWB SPACER CLIP (B)	85	6183	JUNCTION BOX COVER
37	6136	PUBBER BUSH	86	6184	AIR PRESSURE SW
38	6137	CORD CONNECTOR	87	6185	LEG
39	6138	CARRYING HANDLE	88	6186	SENSOR ASSY
40	6139	POWER SUPPLY CORD	89	6037	LEVEL GUIDE
41	6140	BLOWER ASSY	90	6068	WINDOW PLATE
42	6141	BLOWER MOUTH PACKING	91	6069	WINDOW GLASS
43	6142	DAMPER SOLENOID ASSY	92	4004	JOINT PIPE
44	6143	SUCTION CASE	93	4805	AIR OUTLET CAP
45	6144	SEAL PACKING	94	4006	PIPE HOLDER
46	6145	AIR SUPPLY HOSE ASSY	95	4008	HOSE BAND
47	6146	AIR DAMPER	96	4014	EXHAUST OUTLET CAP
48	6147	FLUE PIPE ASSY	97	4016	AIR PORT O RING
49	6148	SLEEVE FLANGE SET	98	4833	CORD BUSHING